

Parts list and mounting instruction

Best. No.: 7564 ES YA XT 660 R

Article: Off/Road Protection Guard, black

1 pair of guards

1 x Parts list and mounting instruction

6 x Strap straight

Strap in Protection Guard:

6 x Hexagon Screw

DIN 933

M 10 x 20 mm

6 x Washer

DIN 125

M 10

Mounting parts on top left:

1 x Ribbed inserts for tube ends

SRL 25

1 x Strap with welded tube

Strap in motorcycle:

1 x Threaded rod

M 10 x 160 mm

1 x Washer

DIN 125

M 10

1 x Lock washer

DIN 6797

M 10

1 x Hexagon nut

DIN 934

M 10

Mounting parts on top right:

1 x Ribbed inserts for tube ends

SRL 25

1 x Strap twice bent

Strap in motorcycle:

1 x Washer

DIN 125

M 10

1 x Lock washer

DIN 6797

M 10

1 x Hexagon nut

DIN 934

M 10

Mounting parts middle:

1 x Hexagon Screw

DIN 931

M 10 x 120 mm

2 x Washer

DIN 125

M 10

1 x Hexagon nut

DIN 985

M 10

2 x Distance tube

18 x 4 x 15 mm

Mounting parts below:

1 x Hexagon Screw

DIN 931

M 10 x 130 mm

2 x Washer

DIN 125

M 10

1 x Hexagon nut

DIN 985

M 10

2 x Distance tube

18 x 4 x 20 mm

(is cancelled with combined assembly with our engine guard 7568)

2 x Distance tube

18 x 4 x 15 mm

(it is used only with combined assembly with our engine guard 7568)

Protection Guard in motorcycle:

2 x Hexagon Screw

DIN 933

M 10 x 25 mm

4 x Washer

DIN 125

M 10

2 x Hexagon nut

DIN 985

M 10

Datum/Name	Erstellt	Geändert	Geprüft Entwicklung	Geprüft Verkauf	Freigabe
	2012-01-19 PK				



Picture 7564



Picture 7564_M

Mounting instruction:

- Plastic side Fairing decreases.
- Connection on top on the right: Screw of the ignition coil remove, ignition coil high press.
- Engine hold screw against our threaded rod M 10 x 160 mm exchange.
- Flaps push open (surface to the Frame) and with the listed mounting parts screw on loose.
- Just flaps with the listed mounting parts loose in the Protection Guard screw on.
- Original screws by the middle and lower connection remove.
- Mount the Protection Guard with the further listed mounting parts loose in the motorcycle, Protection Guards aim and screw together everything.
- The Distance tubes are mounted in each case between Protection Guard and Frame.
- Ignition coil again fasten.
- Plastic Fairing again mounts.
- **Remove not all engine hold screws all at once, otherwise the engine can sink.**
- Anzieh torques for bolts and nuts like from the manufacturer given (if not given: M 4: 3 nm, M 5: 5.9 nm, M 6: 10 nm, M 8: 25 nm, M 10: 49 nm, M 12: 85 nm).
- Screws if necessary with liquid screw protection again mount.

Care and servicing:

To reach a long live span of our chromium-plated articles they should be cleaned regulary and be treated with customary chrome care means.

With powder coated articles a regular cleaning is important. Damages (e.g. by rockfall) can be mended with colour.

By both versions we recommend about the winter the spraying or rubbing with corrosion protection oil or silicone.

All fixing bolts must be checked at regular intervals (max. 6 months).

We wish you a lot of joy and accident-free journey with our motorcycle accessories.